



The bridge to possible

Best Practice on Successful Deployment of Webex Expert on Demand on Augmented Reality Devices

BRKCOL-2991

José Rico | Technical Solution Architect at Cisco
@_Jose_Rico



BRKCOL-2991

Cisco Webex App

Questions?

Use Cisco Webex App to chat with the speaker after the session

How

- 1 Find this session in the Cisco Live Mobile App
- 2 Click “Join the Discussion”
- 3 Install the Webex App or go directly to the Webex space
- 4 Enter messages/questions in the Webex space

Webex spaces will be moderated until February 24, 2023.






Agenda

- What is “Webex Expert on Demand” ?
 - Introduction to the "Webex Expert on Demand" solution
- Deployment of “Webex Expert on Demand” on a RealWear device
- Deployment of “Webex Expert on Demand” on a Google Glass device
- Demo of the “Webex Expert on Demand” solution
- TAC Solution Support
- Conclusions and Key Takeaways

Welcome to my session





José Rico
Technical Solution Architect at Cisco



What is
“Webex Expert on
Demand” ?

Webex Expert on Demand

Hands-free collaboration to the frontline




Deliver the power of hands-free collaboration to the frontline.
Equip your frontline workers for smarter, safer hybrid work



Webex Expert on Demand


Hands-free collaboration to the frontline



Deliver the power of hands-free collaboration to the frontline.
Equip your frontline workers for smarter, safer hybrid work




Hands-free collaboration to the frontline




Deliver the power of hands-free collaboration to the frontline.
Equip your frontline workers for smarter, safer hybrid work



Hands-free collaboration to the frontline



Powering hybrid work by enabling enterprise-wide collaboration



For remote experts

- Full set of Webex App and Meetings capabilities
- Easily add additional participants on the fly
- Content sharing, annotation and whiteboarding
- Flexible layout and stage view for meetings
- Recording

For frontline workers

- Real-time video with one or multiple experts
- Start a call through recent contacts, directory, and dedicated team space
- Join Webex scheduled meetings with voice commands
- Request help for immediate assistance
- Capture, share and annotate images
- Integrate digital workflows
- Enhance noise cancellation
- Transmit 1080p video to remote experts
- Option to enable remote control

Webex Expert on Demand



+



RealWear HMT-1®

RealWear HMT-1Z1®




RealWear Navigator™ 500



Deployment of “Webex Expert on Demand” on a RealWear device

Deployment of “Webex Expert on Demand”

Device Management for RealWear device




Android-based wearable glass devices do not have access to the Play Store to download application.

With RealWear own MDM cloud solution – RealWear Cloud



With an own Mobile Device Management



*The Mobile Application Management License Agreement is an agreement made by and between Cisco and another organization or licensee looking to wrap the mobile application. The MAM agreement secure our IP and avoid re-engineering.


** A Cisco CCO account is required to receive the MAM application. If you do not have one, please apply for one at :

<https://id.cisco.com/signin/register>

BRKCOL-2991

© 2023 Cisco and/or its affiliates. All rights reserved. Cisco Public

13



Deployment of “Webex Expert on Demand”

On a RealWear device




Deployment of “Webex Expert on Demand”

On a RealWear device - Prerequisites

- The following steps must be completed before you can assign “Webex Expert on Demand” app via RealWear Cloud on the glasses:
- Purchase of the "Webex Expert on Demand" license per device
- Device created in the Control Hub
- Create a RealWear Cloud Workspace

Note:


Existing “Webex Expert on Demand Named User” license need to migrate to new “Webex Expert on Demand Device” license -> [A-FLEX-XOD-DEVICE](#)



Deployment of “Webex Expert on Demand”

On a RealWear device – Preparation



- To register the device in the RealWear Cloud, you need the serial number.
- Turn on the RealWear glasses.
- With the words "My Programs" and then "About Device", you get the serial number displayed.



Deployment of “Webex Expert on Demand”

On a RealWear device – Creating a new RealWear Device

- Navigate to the RealWear Cloud portal
- Select “Devices”



- Click the plus icon to add a new device



Deployment of “Webex Expert on Demand”

On a RealWear device – Creating a new RealWear Device

- Fill in the necessary fields and click “Insert Device”

Add Device

<div>Serial Number *</div> <div>MPA6N106D2357232</div> <div>Enter a valid Device Serial Number</div>	<div>Subsidiary</div> <div>Subsidiary (optional)</div>
<div>Friendly Name *</div> <div>Webex Expert on Demand Nav500 Demo</div> <div>Name</div>	<div>Department</div> <div>Department (optional)</div>
<div>Email Address</div> <div>Email Address (optional)</div>	<div>City</div> <div>City (optional)</div>
<div>Device Description</div> <div>Description (optional)</div>	<div>Country</div> <div>Country (optional)</div>
<div>Company</div> <div>Cisco Systems</div> <div>Company (optional)</div>	

Back



Insert Device



Deployment of "Webex Expert on Demand"

On a RealWear device – Creating a new RealWear Device

- Select "Applications" and under "My Apps" install the "Cisco Expert on Demand" application.



Webex Expert on Demand integrated in RealWear




Front View Callout Definitions

Callout	Definition	Callout	Definition
1	Active camera indicator light	8	Camera
2	Shoulder joint	9	Elbow joint
3	Flashlight	10	Action Button
4	Display pod	11	Power button/fingerprint sensor
5	Mic A1 (Mic A2 opposite side)	12	Speaker
6	Mic B1 (Mic B2 on opposite side)	13	Side accessory clipping points
7	Boom arm	14	Left and right buttons



Rear View Callout Definitions


Callout	Definition	Callout	Definition
1	Battery pack	6	Rear band
2	Display window	7	Camera module
3	3.5 mm audio jack	8	Battery status indicator
4	USB-C charging port	9	Dust cover
5	Micro SD card slot cover		



Deployment of “Webex Expert on Demand” on a Google Glass device

Deployment of “Webex Expert on Demand”

Device Management for Google Glass device




Android-based wearable glass devices do not have access to the Play Store to download application.

Google does not offer its own MDM solution for its Google Glass devices.

Cisco recommends that customers in enterprise environments use an MDM solution to manage and push the “Webex Expert on Demand” application to Google Glass devices.

With an own Mobile Device Management (Cisco recommendation)



*The Mobile Application Management License Agreement is an agreement made by and between Cisco and another organization or licensee looking to wrap the mobile application. The MAM agreement secure our IP and avoid re-engineering.


** A Cisco CCO account is required to receive the MAM application. If you do not have one, please apply for one at :

<https://id.cisco.com/signin/register>




Deployment of “Webex Expert on Demand”

Device Management for Google Glass device




Android-based wearable glass devices do not have access to the Play Store to download application.

Directly on the Google Glass device (only good option for one to two glasses in lab or demo not for production environment)



With an own Mobile Device Management (Cisco recommendation)



*The Mobile Application Management License Agreement is an agreement made by and between Cisco and another organization or licensee looking to wrap the mobile application. The MAM agreement secure our IP and avoid re-engineering.

** A Cisco CCO account is required to receive the MAM application. If you do not have one, please apply for one at :

<https://id.cisco.com/signin/register>



Deployment of “Webex Expert on Demand”

On a Google Glass device

Webex Expert on Demand


How to get "Webex Expert on Demand" App
on the Google Glass Enterprise Edition 2



Deployment of “Webex Expert on Demand”




On a Google Glass device - Prerequisites

- The following steps must be completed before you can install the APK on the glasses:
- Purchase of the "Webex Expert on Demand" license per device
- Device created in the Control Hub
- Sign the MAM agreement to receive the “Webex Expert on Demand” APK software.



Deployment of “Webex Expert on Demand” On a Google Glass device


- Navigate to the “Android Flash Tool”
- Allow ADB access



Deployment of “Webex Expert on Demand”

On a Google Glass device – Device preparation






- I assume that the Android USB driver is already installed.
- Next, the Developer Mode must be activated in the Google Glass glasses.



Deployment of “Webex Expert on Demand”

On a Google Glass device - Device preparation

- Under the system setting
 - Enable “Developer Options
 - Enable “USB Debugging”




Deployment of “Webex Expert on Demand”

On a Google Glass device - Device preparation


Sometimes you have to select the USB Configurator additionally.

- About Device -> Android Settings -> Systems -> Developer Options -> Select USB Configuration -> MTP




Deployment of “Webex Expert on Demand”

On a Google Glass device – Connect device and install APK



Deployment of “Webex Expert on Demand”

On a Google Glass device – Connect device and install APK



Webex Expert on Demand integrated with Google




Demo of the “Webex Expert on Demand” solution

Quick, secure login using QR code

Via <https://expert-on-demand.webex.com/> link

Use Expert on Demand
QR code login to access
your user profile to start
collaborating with your
team of experts




Expert on Demand

Generate a code to link your Webex account.
If you need more information, [click here](#).

☐ I'm running v1.9.0.0 or newer

[Generate code](#)

Need Help Signing in? [Contact Support](#)



Expert on Demand

Generate a code to link your Webex account.
If you need more information, [click here](#).

☒ I'm running v1.9.0.0 or newer

[Sign In](#)

Need Help Signing in? [Contact Support](#)

Scan this code to link your Webex account.
If you need more information, [click here](#).



[01:58](#)

Need Help Signing in? [Contact Support](#)

Instant access to remote expertise when you need it most




Call your recent contacts



Enable your company directory




Call dedicated team space




Voice recognition makes searches simple


- Voice recognition technology to search for words like “groups” and “teams”
- Experience Webex background noise removal during calls



Join Webex meetings from anywhere




Remote experts can share their screen with the frontline worker to provide real-time guidance



Frontline worker can view the documentation and use it to solve the problem in front of them or screen shot for later use

Join scheduled meetings from your device anywhere, anytime

Join scheduled Webex meetings with your Glass



All eyes on the frontline with advanced video layouts

Remote experts select advanced and flexible video layout

All eyes are on the frontline worker, regardless of who is speaking



Drag and drop participants




Scroll between participants



Stage and stack to your liking



Use slider controls to customize



Support of English

Help identify the resolution with simple annotation


The remote expert can annotate what the frontline worker is seeing using their laptop, tablet, smartphone, Webex Desk Pro, Webex Board, Webex Desk Mini or Webex DX80




Annotate with simple voice-activated commands and head tracking



Place annotations with head tracking movements



User annotation options to select pointer and color options



User can add multiple annotations, undo annotation and eventually save or discard


Pinpoint the issue with manual and auto focus modes

Switch between manual and auto focus modes




Document, zoom, and pan

User can zoom on the content shared by remote expert and pan document using head movements



Zoom Level 1



Zoom Level 3



Webex Expert on Demand TAC Solution Support


How customers, Partners, and Cisco fit together

How Solution Support works



Webex Expert on Demand

How to send log data to the TAC Solution Support team



Open a TAC case

Helpful Link

[Technical Support Services At-a-Glance](#)

Information you need to create a service request:

- Valid Cisco.com User ID
- Active support contract number
- Problem description and symptoms.
 - Webex Expert on Demand logged users email address.
 - Information when the logs were created and sent.
 - Software version of Webex Expert on Demand application *
 - Installed Firmware version of device
 - Hardware model
- Severity level S1 – S4 of your case

* Webex Expert on Demand software version:

- My Programs -> Settings -> Apps & Notifications -> See All Apps (Select Item 5) -> Expert on Demand -> Advanced -> Version X.X.X





Webex Expert on Demand


How to send log data to the TAC Solution Support team

Open Webex Expert on Demand application.

Say the words "*Menu*", "*Help*" and then "*Send Logs*".



Frontline...
HIDE MENU
NO NOISE
OFF
HELP
SIGN OUT



Conclusions and Key Takeaways



Conclusion and Key Takeaways

- Webex Expert on Demand is easy to install and to use
- Efficient – Limiting Downtime & Boosting Productivity
- Cost Saving – Lowering Operating Costs
- Effective – Faster Onboarding



Appendix



- [Webex Expert on Demand webpages \(Solution / Frontline\)](#)
- [What's New in Webex Expert on Demand \(Subscribable\)](#)
- [Help Webex articles](#)
- [Webex Expert on Demand – YouTube Channel](#)
- [Join Ask Webex Expert on Demand space \(Cisco internal\)](#)
- [Cisco Webex Expert on Demand – Community Page](#)
- [Webex Expert on Demand – 30 days Trial Request – Form](#)
- [Webex Expert on Demand – PM Mailer List](#)



- [Solution Overview](#)
- User Guides [HMT-1](#) | [Navigator 500](#)
- [RealWear Explorer](#)
- [RealWear products comparison](#)
- [RealWear support](#)
- RealWear Cloud (formerly RealWear Foresight)
 - [Knowledge Base](#) | [RealWear Cloud Dashboard](#)



- [FAQ](#)
- [Glass Enterprise Edition 2 support](#)
- [Glass Enterprise APK installation](#)



Time for Q&A

Continue Your Education



Visit the Cisco Showcase for related demos.



Book your one-on-one Meet the Engineer meeting.



Attend any of the related sessions at the DevNet, Capture the Flag, and Walk-in Labs zones.



Visit the On-Demand Library for more sessions at ciscolive.com/on-demand.

Complete your Session Survey

- Please complete your session survey after each session. Your feedback is very important.
- Complete a minimum of 4 session surveys and the Overall Conference survey (open from Thursday) to receive your Cisco Live t-shirt.
- All surveys can be taken in the Cisco Events Mobile App or by logging in to the Session Catalog and clicking the "Attendee Dashboard" at <https://www.ciscolive.com/emea/learn/sessions/session-catalog.html>





The bridge to possible

Thank you

CISCO *Live!*

CISCO *Live!*

ALL IN