

CISCO *Live!*



#CiscoLive



The bridge to possible

# Using IOT + Collab + Meraki API's for a safer return to the school

Helmut Heise, DSM  
@HelmutHeise  
DEVNET-1416

Hector Morales, TSA  
@ekktor

# Cisco Webex App

## Questions?

Use Cisco Webex App to chat with the speaker after the session

## How

- 1 Find this session in the Cisco Live Mobile App
- 2 Click “Join the Discussion”
- 3 Install the Webex App or go directly to the Webex space
- 4 Enter messages/questions in the Webex space

Webex spaces will be moderated by the speaker until June 17, 2022.



<https://ciscolive.ciscoevents.com/ciscolivebot/#DEVNET-1416>

# Abstract

During 2020 1.5 billion of students were taken off from schools due to the COVID-19 pandemic. Different methodologies were applied to make students, professors, school staff and parents environments much safer before vaccination, with mixed results. In 2021, different scientific papers discussed a very simple but powerful way to prevent COVID19 contagions by measuring CO2 levels in the room. In this session, we will provide a simple solution using a cloud connected CO2 meter with wireless mesh and in combination with Meraki Scanning API, we will provide safer metrics for room utilization. Webex API's will provide the feedback and messaging mechanism to send real time alarms when necessary.



# Agenda


- Background, Framework and High-level concept
- Meraki Scanning API
- Meraki and DNA Spaces integration
- CO2 meters + Meraki MR as sensors
- Sensors and Room Utilization Application Integration
- Webex Bot – real-time reporting
- Demo
- Q&A

# Background, Framework and High-Level Concept



# Background

- SARS-CoV-2 transmission via aerosols – tiny droplets that do not settle due to gravity – is known to play some role in the pandemic [1].
- In rooms without technical air refreshing systems, the aerosol concentration can be reduced with simple natural ventilation activity [2].
- CO<sub>2</sub> monitoring could be implemented as a COVID-19 risk mitigation tool in restaurants [3].
- There is a direct positive correlation of number of people in a room via CO<sub>2</sub> concentration and the risk of infection [4]




SOURCE - Changes in CO<sub>2</sub> concentration in the conference room from “Recommendations for ventilation of indoor spaces to reduce COVID-19 transmission”, Chung-Yen Chen et-al. 5 August 2021. <https://www.sciencedirect.com/science/article/pii/S092966462100365X>

# Proposal


- Based on the research there are two facts:
  - CO2 concentration determines the risk of COVID19 contagion
  - Room characteristics such as ventilation and actual space, determines the amount of people in a room
- Due to current vaccination limitations, not all countries are able to vaccinate all population, leading to continues risk of COVID19 peaks
- Young population, between 5 and 18 years, might be subject of contagion due to school attendance and lack of vaccination in some places.
- CO2 concentration and Room occupancy can be determined and actions to make decisions can be automated



# Framework




# High Level concept




# Meraki Scanning API




# How Scanning API works



# Meraki Scanning API flow



# Configuring Scanning API



## Location and scanning ⓘ

Analytics

Analytics enabled ▾

Scanning API

Scanning API enabled ▾

Validator ⓘ

8c919de11e973a619ca35baa8c1787ec

Validated <http://cisco-amsterdam.live:5013>

Post URLs ⓘ

Status ⓘ	Post URL	Secret	API Version	Radio Type		
<input type="radio"/>	<a href="http://yourserver.com:5000">http://yourserver.com:5000</a>	supersecret <small>hide secret</small>	V3 ▾	WiFi ▾	Validate	✕

[Add a Post URL](#)

Your own server

DNA Spaces

<CODE HERE>

## Location and scanning ⓘ

Analytics

Analytics enabled ▾

Scanning API

Scanning API enabled ▾

Validator ⓘ

8c919de11e973a619ca35baa8c1787ec

# Meraki + DNA Spaces integration



# Meraki and DNA Spaces integration

## 1 – Add new wireless network



### Get your wireless network connected with Cisco DNA Spaces

There are multiple options to get connected based on your wireless network deployment.

+ Add New

### What type of wireless network do you have?

Cisco DNA Spaces works with most Cisco wireless networks including Cisco Meraki.

#### Cisco AireOS/Catalyst

Choose this for Cisco Aironet Access Points with Cisco Wireless LAN Controllers (WLC) or CMX On-Prem Tethering.

Select

#### Cisco Meraki

Choose this for Cisco Meraki networks with Meraki MR Access Points

Select

Need help? Use this planning guide to decide the best suited option based on your network.



# Meraki and DNA Spaces integration

## 2 – Add Meraki API Key

Choose your preferred method of connecting Cisco Meraki with Cisco DNA Spaces.

### Connect via API key

You can connect DNA Spaces to your Meraki account using an API Key

TIP: Follow the steps to create API key: Login to meraki dashboard > Click Profile icon (top right corner) > API access > API keys and click Create API Key

Select

Need help? Use this planning guide to decide the best suited option based on your network

Generate an API Key in Meraki Dashboard

Confirm password

Change password

Two-factor authentication

SMS authentication is OFF.

Set up two-factor authentication

API access

API keys

Key

\*\*\*\*\*

Generate new API key

**New API key**

Your API key is

9194504d4e55590c5f03684d59086e920a4003e1

**Copy and store your API key in a safe place**

Dashboard does not store API keys in plaintext for security reasons, so this is the *only* time you will be able to record it. If you lose or forget your API key, you *will have to revoke it and generate a new one.*

☒ I have stored my new API key

Done


# Meraki and DNA Spaces integration

1

## Connect your Meraki

Connect Meraki with DNA Spaces using the API key.

MERAKI SYNCHRONIZATION

 active

Currently 0 other DNA Spaces login is syncing

YOUR LOGIN



**Your login is not connected**

You will not be able to make changes to Meraki sync. Connecting your Meraki account will let you to import Meraki networks into the Location Hierarchy

[Connect](#)

## Connect via API key

Enter your Meraki API Key to fetch the network information

API KEY

9194504d4e55590c5f03684d5 fc55507c6780d5e

[Connect](#)

# Meraki and DNA Spaces integration


## 3 – Connect via Meraki API Key

### Connect via Meraki API Key

Connect Cisco DNA Spaces to Meraki Cloud Controller using your Meraki API key.

#### 1 Connect your Meraki

Connect Meraki with DNA Spaces using the API key.

MERAKI SYNCHRONIZATION active	Currently 0 other DNA Spaces login is syncing
YOUR LOGIN	
 Your login is not connected You will not be able to make changes to Meraki sync. Connecting your Meraki account will let you to import Meraki networks into the Location Hierarchy	<a href="#">Connect</a>

#### 2 Configure Meraki scanning API

Configure below Post URL with URL validator and secret key and validate manually in Meraki dashboard to establish connection with DNA Spaces.

Post URL

https://location.dnaspaces.io/notifications/Meraki/hectormorales/<network\_id>/<URLValidator>



Secret Key

hectormorales



0

networks configured

#### 3 Import Meraki Networks into Location Hierarchy

Connect Meraki with DNA Spaces using the API key.

0 networks imported	<a href="#">Import Networks</a> <a href="#">Sync Status</a>
---------------------	--

# Meraki and DNA Spaces integration

2

## Configure Meraki scanning API

Configure below Post URL with URL validator and secret key and validate manually in Meraki dashboard to establish connection with DNA Spaces.

Post URL

https://location.dnaspaces.io/notifications/Meraki/hectormorales<network\_id><URLValidator>



Secret Key

Get network id from Meraki Organization API



Get URL Validator from Meraki Network wide General

0 networks configured

[Meraki Dashboard API Documentation](#)

# Meraki and DNA Spaces integration

Get network id from the organization

2

## Configure Meraki scanning API

Configure below Post URL with URL validator and secret key and validate manually in Meraki dashboard to establish connection with DNA Spaces.

Post URL

https://location.dnaspaces.io/notifications/Meraki/hectormorales<network\_id>/<URLValidator>

Secret Key

hectormorales

0 networks configured

https://n168.meraki.com/api/v0/organization

▼ 5:

id:

"657525545596093462"

name:

"ACME SD-WAN"

▼ url:

"https://n168.meraki.com/o/zi7yVc0c/manage/organization/overview"

https://n168.meraki.com/api/v0/organizations/657525545596093462/networks

▼ 0:

id:

"L\_657525545596103966"

organizationId:

"657525545596093462"

name:

"HQ Site"

timeZone:

"America/Los\_Angeles"

tags:

null

▼ productTypes:

0:

"appliance"

1:

"wireless"

type:

"combined"

disableMyMerakiCom:

false

disableRemoteStatusPage:

true

CISCO *Live!*

#CiscoLive


DEVNET-1416

© 2022 Cisco and/or its affiliates. All rights reserved. Cisco Public

21

# Meraki and DNA Spaces integration

## Get Validator



### Location and scanning ⓘ

Analytics

Analytics enabled ▾

Scanning API

Scanning API enabled ▾

Validator ⓘ

78611973c567c767efec11eb7706ca34ba56ad4309

Post URLs ⓘ

HTTPS is required for Scanning API receivers. Your API documentation: <https://developer.cisco.com/m>

Status ⓘ

Post URL



<http://live-demo22.online:5013/>



<https://location.dnaspaces.io/notificatio>

[Add a Post URL](#)

# Meraki and DNA Spaces integration

## Validate URL

☐   [Show secret](#) V3 ▾ WiFi ▾ Validate ✕

<https://location.dnaspaces.io/notifications/Meraki/hectormorales/tSHabcw/973a619ca35ba8c919de11eba8c1787ec0611423>

**You have unsaved changes.**

or [cancel](#)

[<CODE HERE>](#)

# CO2 meter and Meraki MR as sensors






# Solution components


1. Get CO2 room values
2. Get number of people on the room
3. Dynamic Room Calibration
4. Dynamic Thresholds
5. Publish room information
6. Inform when actions must be taken

# Get CO2 room values



[GrowFlux API Documentation](#)


# Get number of people on the room




# Sensors and Room Utilization Application Integration



# Dynamic Room Calibration



# Dynamic Thresholds



CO2 levels + People in the room

Danger zone

Safe zone





<CODE HERE>

# Webex Bot – real-time information



# Create a Bot account

<https://developer.webex.com/>



Bot

Build chatbots that post content and  
respond to commands.

Create a Bot

Learn More



# Get your bot's access token

**Congratulations!** 🎉



Cisco Live is one step closer to becoming a reality.

## Cisco Live

👉 **Next Step:** Use your Bot Access Token to set up your webhook and finish building your bot.

### Bot access token

Non-expiring (good for 100 years)  
access token for your bot. Save  
this token to set up your  
webhook.

 N2Q0YjAtMTIkMC0ZWQzLTkzYzktMDNIYjhiN2JmMmQ?=

Copy Token

💡 **Tip:** Save this token!

It won't be shown again (but you can regenerate a new one if needed).

# Webex Python SDK

<https://github.com/CiscoDevNet/webexteamssdk>

[ec2-user@ip-172-31-31-54 live]\$ pip3 install webexteamssdk

Bot and API  
Auth

```
import requests
from webexteamssdk import WebexTeamsAPI
from flask import Flask, request
from flask_httpauth import HTTPBasicAuth

# Bot Token and object #
BOTOKEN = "OWUxN2Q0YjAtMTlkMC00ZWQzLTkzYzktMDNlYjhiN2JmMmQ2MzQ2ZjRkMzEtZDc5_PF84_1eb65fdf-9643-417f-9974-ad72cae0e10f"
live_bot = WebexTeamsAPI(access_token=BOTOKEN)

### Flask ###
app = Flask(__name__)


auth = HTTPBasicAuth()

users = {
    "hemorale": "Cisco123",
    "hheisego": "Cisco123"
}

@auth.verify_password
def verify_password(username, password):
    if username in users and password in users[username]:
        return username
```


<CODE HERE>

# Publish room information



- Room with y number of people
- CO2 measurement of y
- Provide room insights based on data
- Inform via Webex Bot

# Inform when actions must be taken



CO2 levels

Red zone → Better run!!

Yellow zone → Open windows

Green zone → Be happy

# Demo Putting all together



# Our demo running live...



Cisco Live Yesterday, 8:29 PM

Device mac: c2:3a:b0:30:3c:29

RSSI: -55

CO2: 333 | Devices count: 1

Timestamp: 2022-06-11 20:29:21.530

CO2 levels: 333

Temperature: 20.04

Humidity: 59.48

Voltage: 3.42

Pressure: 74.14

# Q&A



# References

- 1) O'Keeffe J, Freeman S, Nicol A-M. The basics of SARS-CoV-2 transmission [evidence review]. Vancouver, BC: National Collaborating Centre for Environmental Health; 2021 Mar 21. Available from: <https://ncceh.ca/documents/evidence-review/basics-sars-cov-2-transmission>.
- 2) CO2 measurements in instrumental and vocal closed room settings as a risk reducing measure for a Coronavirus infection. Manfred Nusseck, Bernhard Richter, Ludwig Holtmeier, Dominik Skala, Claudia Spahn. medRxiv 2020.10.26.20218354; doi: <https://doi.org/10.1101/2020.10.26.20218354>
- 3) Eykelbosh, A. Indoor CO2 Sensors for COVID-19 Risk Mitigation: Current Guidance and Limitations. Vancouver, BC: National Collaborating Centre for Environmental Health. 2021 May. <https://ncceh.ca/documents/field-inquiry/indoor-co2-sensors-covid-19-risk-mitigation-current-guidance-and>
- 4) Changes in CO2 concentration in the conference room from “Recommendations for ventilation of indoor spaces to reduce COVID-19 transmission”, Chung-Yen Chen et-al. 5 August 2021. <https://www.sciencedirect.com/science/article/pii/S092966462100365X>
- 5) University of Colorado at Boulder. "Carbon dioxide levels reflect COVID-19 risk: Research confirms value of measuring carbon dioxide to estimate infection risk." ScienceDaily. ScienceDaily, 7 April 2021. <[www.sciencedaily.com/releases/2021/04/210407143809.htm](http://www.sciencedaily.com/releases/2021/04/210407143809.htm)>.



# Technical Session Surveys

- Attendees who fill out a minimum of four session surveys and the overall event survey will get Cisco Live branded socks!
- Attendees will also earn 100 points in the Cisco Live Game for every survey completed.
- These points help you get on the leaderboard and increase your chances of winning daily and grand prizes.



# Cisco Learning and Certifications

From technology training and team development to Cisco certifications and learning plans, let us help you empower your business and career. [www.cisco.com/go/certs](https://www.cisco.com/go/certs)

## Pay for Learning with Cisco Learning Credits

(CLCs) are prepaid training vouchers redeemed directly with Cisco.



## Learn

### Cisco U.

IT learning hub that guides teams and learners toward their goals

### Cisco Digital Learning

Subscription-based product, technology, and certification training

### Cisco Modeling Labs

Network simulation platform for design, testing, and troubleshooting

### Cisco Learning Network

Resource community portal for certifications and learning



## Train

### Cisco Training Bootcamps

Intensive team & individual automation and technology training programs

### Cisco Learning Partner Program

Authorized training partners supporting Cisco technology and career certifications

### Cisco Instructor-led and Virtual Instructor-led training

Accelerated curriculum of product, technology, and certification courses



## Certify

### Cisco Certifications and Specialist Certifications

Award-winning certification program empowers students and IT Professionals to advance their technical careers


### Cisco Guided Study Groups

180-day certification prep program with learning and support

### Cisco Continuing Education Program

Recertification training options for Cisco certified individuals

Here at the event? Visit us at **The Learning and Certifications lounge at the World of Solutions**



# Continue your education

- Visit the Cisco Showcase for related demos
- Book your one-on-one Meet the Engineer meeting
- Attend the interactive education with DevNet, Capture the Flag, and Walk-in Labs
- Visit the On-Demand Library for more sessions at [www.CiscoLive.com/on-demand](https://www.CiscoLive.com/on-demand)



The bridge to possible

# Thank you

CISCO *Live!*



#CiscoLive